

Busy Output

For the duration of an announcement the busy output will be activated . With aid of 2 jumpers it can be configured to the following functions.

Busy Output	Jumper JP 1	Jumper JP 2
Open Collector 	X	O
Pull up 	O	X
Pull down 	X	X
Opto-Koppler Output 	O	O

O = open
X = closed

x 2-1= Outputterminal 1
x 2-2= Outputterminal 2

U in = U – Power input from the Module